



**If I have chosen to vent through the rear corner posts,
can I leave the tarp closed and still unload grain?**

No, depending of the speed at which you unload the trailer, it may still generate too great of an suction and damage the trailer or tarp system.

See Your Local Timpte Branch For All Your Parts And Service Needs!

© 2011 Timpte Inc.

www.timpte.com